

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>1.</b>		<b>HEDDLE BAND</b> Ref : 3UA-1527	<b>2.</b>		<b>HEDDLE BAND</b> Ref : 2UA-1528
<b>3.</b>		<b>HEDDLE BAND</b> Ref : 3UA-1308	<b>4.</b>		<b>HEDDLE BAND</b> Ref : 2UA-1309
<b>5.</b>		<b>HEDDLE BAND</b> Ref : 3UA-1954	<b>6.</b>		<b>HEDDLE BAND</b> Ref : 2UA-1955
<b>7.</b>		<b>COMPLETE BEARING BLOCK</b> Ref : YVC-0192	<b>8.</b>		<b>BEARING BLOCK</b> Ref : 2AA-3123
<b>9.</b>		<b>COMPLETE EXCENTRE ROLL</b> Ref : YVC-0213	<b>10.</b>		<b>EXCENTRE ROLL</b> Ref : 4CC-3365
<b>11.</b>		<b>COMPLETE CHONCHOID ROLLER</b> Ref : YVC-0246	<b>12.</b>		<b>CHONCHOID ROLLER</b> Ref : 3CB-3528
<b>13.</b>		<b>COMPLETE CHONCHOID ROLLER</b> Ref : YVC-0189	<b>14.</b>		<b>CHONCHOID ROLLER</b> Ref : 3CE-0349

ООО "ИНВЕНТ СЕРВИС"

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>15.</b>		<b>COMPLETE CHONCHOID ROLLER</b> Ref : YVC-0247	<b>16.</b>		<b>CHONCHOID ROLLER</b> Ref : 3CB-3531
<b>17.</b>		<b>COMPLETE BRAKE ROLLER</b> Ref : YVC-0183	<b>18.</b>		<b>BRAKE ROLLER</b> Ref : 3CE-1972
<b>19.</b>		<b>COMPLETE SHUTTLE WHEEL</b> Ref : YVC-0245	<b>20.</b>		<b>SHUTTLE WHEEL</b> Ref : 4CC-3534
<b>21.</b>		<b>COMPLETE SHUTTLE WHEEL</b> Ref : YVC-0185	<b>22.</b>		<b>SHUTTLE WHEEL</b> Ref : 4CF-0675
<b>23.</b>		<b>COMPLETE DRIVING ROLL</b> Ref : 4CD-3681 Ref : YVA-0141	<b>24.</b>		<b>SHUTTLE DRIVE ROLLER</b> Ref : 4UB-1564
<b>25.</b>		<b>COMPLETE DRIVING ROLL</b> Ref : YVC-0249	<b>26.</b>		<b>COMPLETE BRAKE ROLL</b> Ref : YVC-0133
<b>27.</b>		<b>BANDAGE</b> Ref : 3UA-0042	<b>28.</b>		<b>LEVER</b> Ref : 2CB-2182

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>29.</b>		<b>COMPLETE INS. FINGER STOPPING DEVICE</b> Ref : YVK-0170	<b>30.</b>		<b>PICK UP - OLD</b> Ref : 3UE-1329
<b>31.</b>		<b>CERAMIC COMPENSATOR</b> Ref : 2CF-3426	<b>32.</b>		<b>PICK UP - NEW</b> Ref : 3UE-1329
<b>33.</b>		<b>SIDE WASHER</b> Ø35 / Ø115 Ref : 2CB-3600	<b>34.</b>		<b>FOAM PLASTIC WASHER</b> Ø113 / Ø47 Ref : 4TA-1097 Ref : 4TA-1645
<b>35.</b>		<b>SIDE WASHER</b> Ref : 3UC-1250	<b>36.</b>		<b>CREEL BOBBIN HOLDER</b> Ref : 3UB-1271
<b>37.</b>		<b>INSERTION FINGER HOLDER</b> Ref : 3CC-3794	<b>38.</b>		<b>BRAKE</b> Ref : 2CC-4153
<b>39.</b>		<b>BRAKE JAW</b> Ref : 2CD-2281	<b>40.</b>		<b>BRAKE BEARING</b> Ref : 3UA-2035
<b>41.</b>		<b>BRAKE BEARING</b> Ref : 3UE-0034	<b>42.</b>		<b>ROLLER</b> Ref : 4UA-1305















## Аналоги запчастей к модели SL 82 (Starlinger)

<b>43.</b>		<b>RETURN PULLEY</b> 118 Ref : 4UA-1204	<b>44.</b>		<b>COMPLETE RETURN PULLEY</b> Ref : YVC-0166
<b>45.</b>		<b>COMPLETE RETURN PULLEY</b> Ref : YVC-0138	<b>46.</b>		<b>CLAMPING PIECE</b> Ref : 3UB-0690
<b>47.</b>		<b>CONNECTING ROD</b> 118 / Ø6 Ref : 2UA-1290	<b>48.</b>		<b>COVER</b> Ref : 3UE-0031
<b>49.</b>		<b>BEARING BLOCK IN FRONT</b> Ref : 3UD-0023	<b>50.</b>		<b>SHUTTLE COVER</b> Ref : 3UC-0544
<b>51.</b>		<b>BRAKE ACTUATING LEVER</b> Ref : 3UB-1918	<b>52.</b>		<b>BRACKET HOLDER</b> Ref : 4UB-0032
<b>53.</b>		<b>CLAMP</b> Ref : 4UA-0029	<b>54.</b>		<b>BASE</b> Ref : 2UB-1655
<b>55.</b>		<b>BRACKET CLAMP</b> Ref : 3UA-1790	<b>56.</b>		<b>BRACKET CLAMP</b> Ref : 4UA-1651

ООО "ИНВЕНТ СЕРВИС"



**Аналоги запчастей к модели SL 82 (Starlinger)**

57.		<b>BRACKET CLAMP</b> Ref : 3UA-2111	58.		<b>BRACKET GROUND PLATE</b> Ref : 4UC-1726
59.		<b>BRACKET CLAMP</b> Ref : 4UA-1727	60.		<b>BRACKET CLAMP</b> Ref : IUD-1659
61.		<b>COMPENSATOR SPACER</b> Ref : 4UD-0279	62.		<b>COVERING</b> Ref : 4UA-1491
63.		<b>COVER</b> Ref : 4UA-1316	64.		<b>COVER</b> Ref : 4UA-1602
65.		<b>COVERING</b> Ref : 4UA-1323	66.		<b>CAP</b> Ref : 4UA-0018
67.		<b>CLAMP RING</b> Ref : 4UB-0093	68.		<b>BUSH</b> Ref : 4UD-0035
69.		<b>BEARING FOR SPRING</b> Ref : 4UB-1287	70.		<b>BEARING F. SPRING</b> Ref : 4UD-0818

## Аналоги запчастей к модели SL 82 (Starlinger)

71.		SIGHT FEED - OILER (D-150 / D-75) Ref : TSE-1014	72.		COMPLETE SPRING LOADED ARM Ref : 3IC-6361 Ref : YVA-0295
73.		COMPLETE SPRING LOADED ARM Ref : 3ID-2633 Ref : YVC-0157	74.		ANGLE Ref : 4IA-6152
75.		ANGLE Ref : 4IA-6151	76.		SUPPORT ANGLE Ref : 4IB-5287
77.		DOWEL PIN Ref : VZS-5056	78.		DOWEL PIN Ref : VZS-5037
79.		DOWEL PIN D5 M6 X 20 Ref : VZS-5027	80.		DOWEL PIN Ref : VZS-5006
81.		DOWEL PIN Ref : VZS-5082	82.		AXLE Ø10 X 94 Ref : 3RB-4887
83.		AXLE Ø10 X 102 Ref : 3RD-3940	84.		AXLE Ref : 3RA-7684











ООО "ИНВЕНТ СЕРВИС"

**Аналоги запчастей к модели SL 82 (Starlinger)**

85.		AXLE Ref : 4RD-3910	86.		ADJUSTING SCREW Ref : 4TC-0001
87.		AXLE Ref : 4RB-7083	88.		AXLE Ø27,5 X 23 Ref : 4RA-6458 Ref : 4AA-1841
89.		BRAKE ROLLER HOLDER 3408-Ref : 4AB	90.		BRAKE ROLLER HOLDER Ref : 4AC-2163
91.		BOLT Ref : 4RC-6945	92.		SHUTTLE WHEEL BOLT Ref : 4RB-7043 Ref : 4AC-2156
93.		BOLT Ref : 4KB-3009	94.		BOLT Ref : 4KA-5441
95.		SLEEVE Ø12 / 17 Ref : 4RB-7168	96.		BOLT Ø10 / 14 - 0,1 Ref : 4RD-3467
97.		BOLT Ref : 4RA-7875	98.		BEARING DISTANCE Ref : 4RA-3686

ООО "ИНВЕНТ СЕРВИС"

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>99.</b>		<b>BEARING DISTANCE</b> Ref : 4RB-3924	<b>100.</b>		<b>FLOATING BUSH</b> Ø20 X 22 Ref : 4BB- 0266
<b>101.</b>		<b>FLOATING BUSH</b> Ref : 4BA-0619	<b>102.</b>		<b>PINTLE</b> Ref : 4AD- 2266
<b>103.</b>		<b>SPACER</b> Ref : 4RA-0021	<b>104.</b>		<b>SPACER D6 / 15 / D10</b> Ref : 4RA- 8848
<b>105.</b>		<b>WASHER</b> Ref : 4RD-3927	<b>106.</b>		<b>SPACER</b> Ref : 4OA- 1021
<b>107.</b>		<b>SPACER Ø25 / 4</b> Ref : 4OB-1464	<b>108.</b>		<b>SPACER Ø5 / 9</b> Ref : 4RA- 6514
<b>109.</b>		<b>SEALING DISC</b> Ref : 4IA-2146	<b>110.</b>		<b>WASHER A6,4</b> Ref : NCS- 1004
<b>111.</b>		<b>PICK UP</b> Ref : 4RB-7880	<b>112.</b>		<b>PICK UP</b> Ref : 4RB- 3930 Ref : 4RB- 7881

ООО "ИНВЕНТ СЕРВИС"



## Аналоги запчастей к модели SL 82 (Starlinger)















113.		COMPLETE BOBBIN TAKE UP FRONT Ref : YVA-0158	114.		COMPLETE BOBBIN TAKE UP REAR Ref : YVA-0159
115.		SAVETY PLUG Ref : 4RB-3933	116.		SAVETY PLUG Ref : 4RA-3956
117.		COVER DISC Ref : 4RA-3958	118.		COVER DISC Ref : 4AA-3685
119.		HOLDER Ref : 4VA-5032	120.		HOLDER Ref : 4VA-5033
121.		HOLDER Ref : 4SA-0128	122.		INSERTION PIPE Ref : 4OA-1912
123.		INSERTION PIPE Ref : 4OA-1914	124.		INSERTION PIPE Ref : 4OA-1911
125.		INSERTION FINGER Ref : 3CC-2757	126.		INSERTION FINGER Ref : 3CC-3438

ООО "ИНВЕНТ СЕРВИС"










## Аналоги запчастей к модели SL 82 (Starlinger)

<b>127.</b>		<b>INSERTION FINGER</b> Ref : 3CC-3439	<b>128.</b>		<b>INSERTION FINGER</b> Ref : 3VB-0169
<b>129.</b>		<b>INSERTION FINGER</b> Ref : 3VB-0281	<b>130.</b>		<b>FOLDING INSERTION FINGER</b> Ref : 3CA-3440
<b>131.</b>		<b>TAPE WEIGHT</b> Ref : 4RA-0548 Ref : 4RB-1841	<b>132.</b>		<b>INSERTION BOW</b> Ref : 3CC-3631 Ref : 3CB-2659
<b>133.</b>		<b>CERAMIC INSERTION FINGER</b> Ref : 4CC-3453	<b>134.</b>		<b>EYELET</b> Ref : 4TA-1891
<b>135.</b>		<b>BEARING BLOCK 118</b> Ref : 2IA-2671	<b>136.</b>		<b>BEARING BLOCK 118 / 100</b> Ref : 3WA-7094
<b>137.</b>		<b>CLAMP RING</b> Ref : VSR-3002	<b>138.</b>		<b>GUIDE BRACKET Ø115</b> Ref : 2OC-1454
<b>139.</b>		<b>GUIDE BRACKET</b> Ref : 2OC-2149	<b>140.</b>		<b>OVER FLOW ARM</b> Ref : 2OC-2150

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>141.</b>		<b>BRACKET</b> Ref : 3FA-0494	<b>142.</b>		<b>COMPENSATOR</b> Ref : 3CC-4464
<b>143.</b>		<b>COMPENSATOR</b> Ref : 3CA-4513 Ref : 3CB-3592 Ref : 3CC-2531 Ref : 3CF-1749	<b>144.</b>		<b>COMPENSATOR</b> Ref : 3CC-4465 Ref : 3CB-3593 Ref : 3CD-2585
<b>145.</b>		<b>THREAD EYE</b> Ref : TOS-1020	<b>146.</b>		<b>FLEXIBLE WIRE</b> 300 MM Ref : TOS-1048
<b>147.</b>		<b>HEDDLE WIRE</b> 340 MM Ref : TOS-1075	<b>148.</b>		<b>SPRING</b> Ø1,1 / Ø9,1 X 58,6 Ref : 4FA-0387
<b>149.</b>		<b>PRESSURE SPRING</b> Ref : 4FB-0008	<b>150.</b>		<b>SPRING</b> Ø1,1 / Ø9,1 X 63 Ref : 4FB-0353
<b>151.</b>		<b>SPRING</b> Ø1,1 / Ø7,6 X 63 Ref : 4FC-0006	<b>152.</b>		<b>SPRING</b> Ref : 4FA-0497
<b>153.</b>		<b>SPRING HOLDER</b> Ref : 4FA-0004 Ref : 4FA-0495	<b>154.</b>		<b>TENSION SPRING</b> Ref : 4FA-0385 Ref : 4FA-0496

## Аналоги запчастей к модели SL 82 (Starlinger)

<b>156.</b>		FELT RING Ref : HDF-1007 Ref : HDF-1038	<b>157.</b>		BUTTON HEAD SCREW M5 X 8 Ref : NSE-3058
<b>158.</b>		FOAMED RUBBER Ø21 X Ø63 X 150 Ref : HDS-1005	<b>159.</b>		SLEEVE Ø35 / Ø40 / 218 Ref : 30A-2237 Ref : 30A-1544 Ref : 30A-2620
<b>160.</b>		RUBBER BAND 100 X 2 Ref : HDG-1093-11800	<b>161.</b>		REFLECTING MATERIAL Ref : ELZ-1033
<b>162.</b>		RUBBER BAND 50 X 2 Ref : HDG-1073-22300	<b>163.</b>		LEATHER INCL. TESA FIX Ref : 4CA-1967 Ref : 4CA-4893
<b>164.</b>		BREAK LINING Ref : 4DA-0113	<b>165.</b>		V BELTS
<b>166.</b>		BALL BEARING	<b>167.</b>		MAGNETIC SENSOR